


Quick Start Guide


IN THE BOX



SkyPro



Smart Charging Case



USB Charging Cable



Your SkyPro turns on automatically when out of its case; SkyPro turns off when correctly* placed back in its case.

- Correctly* place SkyPro into Smart Charging Case (make sure contacts are dry and free of debris)
- Insert Micro-USB to charge your docked SkyPro.
- 3 Flashing LED = charging. Solid LED = charged.
- * SkyPro fits in your Smart Charging Case easily when the knob is resting in the gate of the opposite hinge and screwed in with a few turns. Do NOT force it in the case or force the lid to close.

ATTACH

Our Anti-rotation stability

technology is designed to hold your SkyPro securely on the shaft providing unparalleled precision.

SkyPro can be oriented anywhere on the shaft as long as it is connected just below the grip with the logo pointing down toward the clubhead

Your SkyPro should be attached to the shaft firmly, but don't overdo it. After closing the gate and securing the knob, a few turns after it is snug should be sufficient.

SkyPro's proprietary Smart Calibration technology accurately aligns itself to the clubface to ensure swings are captured accurately.



IMPORTANT: Once your SkyPro is placed on the shaft, and the gate is closed, please do not twist, turn or attempt to reposition your device. This can cause damage to the padding inside the clamp. To adjust your SkyPro, open the gate first and let the hinge hang free before attempting to reposition it on the shaft.

CONNECT





- With your SkyPro nearby, pair its connection with your iOS device
- 2 Tap your iOS device's **Settings** icon, then tap **Bluetooth**
- 3 Tap SkyPro when it appears under Devices

AID TECHNOLOGY

Without changing your pre-shot routine, SkyPro uses proprietary **Auto Impact Detection** (AID) technology to automatically and easily record your swings with unmatched accuracy after each ball strike.



In a restricted environment (such as indoors), a limited-distance ball, or gently brushing a hitting surface (mat, ground, etc.) is required to ensure the capture of your swing and the enjoyment of a hands-free experience powered by SkyPro's exclusive AID technology.



DOWNLOAD

Download the latest SkyPro application for FREE and follow the directions in the app.

Note: Even if you have previously downloaded the app, we regularly release new features and benefits to increase your enjoyment and ease of use. So, downloading the latest app is highly recommended **BEFORE** your first use



